


SAMEDAY SHIPMENT STICKERS - WHAT GOES WHERE?



A snippet of a shipping form with a "SERVICES*" section. It includes checkboxes for "9AM", "AM SERVICE/SERVICE AM", "URGENT LETTER/LETTRE URGENTE", "URGENT PAC/EMBALLAGE URGENT", "PM SERVICE/SERVICE PM", and "GROUND/TERRESTRE".


When shipping a parcel with Sameday Worldwide, following these few simple steps will ensure that your package is shipped the way you want it shipped.

Once you have completed the Bill of Lading (BOL) and selected which service (9AM, AM or PM Service) you require, place the corresponding sticker on the top of the package next to the BOL label. (See example above) All service stickers and labels must be placed **on the top of the package** to ensure they are visible when moving through the Sameday system. Following these simple steps to ensure that the **bar code is visible** and easily captured by our scanners means that your package be **easily tracked** using our on-line track and trace capabilities

Please make sure there is only one address label, bar code label and sticker on each piece.

9AM Service - Delivered by 9AM the next day.
 AM Service - Delivered by Noon the next day.
 PM Service - Delivered by 5PM the next day.

A full Bill of Lading form from Sameday Worldwide. It includes sections for "SHIPPER INFORMATION", "CONSIGNEE INFORMATION", "METHOD OF PAYMENT", and "DECLARED VALUE". It also features a "SERVICES*" section with checkboxes for 9AM, AM, and PM services.



USA/INTERNATIONAL SHIPMENTS

For shipments destined to the USA or Internationally - place the USA Sticker on the package next to the BOL. Please make sure you also use a 9AM, AM or PM sticker as well to indicate which service you are choosing.

